

Table Of Contents

COVER

1 INTRODUCTION

1.1 INTRODUCTION

1.2 ABOUT LEAD FREE SOLDER (PbF)

1.3 IMPORTANT NOTICE 1: (Other than U.S.A. and Canadian Market)

1.4 HOW TO DEFINE THE MODEL SUFFIX (NTSC or PAL model)

1.4.1 Defining methods:

1.4.2 INITIAL SETTINGS:

2 SAFETY PRECAUTIONS

2.1 GENERAL GUIDELINES

2.2 LEAKAGE CURRENT COLD CHECK

2.3 LEAKAGE CURRENT HOT CHECK (See Figure 1.)

3 PREVENTION OF ELECTRO STATIC DISCHARGE (ESD) TO ELECTROSTATICALLY SENSITIVE (ES) DEVICES

4 HOW TO RECYCLE THE LITHIUM ION BATTERY (U.S. ONLY)

5 CAUTION FOR AC CORD (EB only)

5.1 INFORMATION FOR YOUR SAFETY

5.2 CAUTION FOR AC MAINS LEAD

5.2.1 Important

5.2.2 Before use

5.2.3 How to replace the Fuse

6 HOW TO REPLACE THE LITHIUM BATTERY

6.1 REPLACEMENT PROCEDURE

7 OPERATING GUIDE

8 SERVICE NOTES

8.1 WHEN REPLACING THE MAIN C.B.A.

8.2 SERVICE POSITION

8.3 HOW TO DISCHARGE THE CAPACITOR ON MAIN C.B.A.

8.4 CLEANING LENS, VIEWFINDER AND LCD PANEL

9 ADJUSTMENT PROCEDURES

9.1 SERVICE FIXTURE AND TOOLS

10 ERROR CODE MEMORY FUNCTION

11 CONFIRMATION OF FIRMWARE VERSION

12 DISASSEMBLY PROCEDURE

12.1 DISASSEMBLY FLOW CHART

12.2 C.B.A. LOCATION

12.3 DIASSEMBLY PROCEDURE

12.3.1 Removal of the Rear Cover

12.3.2 Removal of the Top Operation

12.3.3 Removal of the LCD Panel

12.3.4 Removal of the Rear Operation Unit and Speaker

12.3.5 Removal of the Main C.B.A.

12.3.6 Removal of the Jack Door Unit

12.3.7 Removal of the SD Card C.B.A.

12.3.8 Removal of the Battery Case

12.3.9 Removal of the CCD Unit

12.3.10 Removal of the EVF Unit

12.3.11 Removal of the Top Case Unit

12.3.12 Removal of the Hot Shoe Unit and Flash Unit

12.3.13 Removal of the Lens unit

12.3.14 Removal of the Lens Ring Front, MF Ring Unit and MF Ring

12.3.15 Removal of the Encoder Unit

12.3.16 Removal of the Side Operation Unit

12.4 DISASSEMBLY / ASSEMBLY PROCEDURE FOR THE LENS

12.4.1 Removal of the Master Flange Unit

12.4.2 Removal of the 4th Frame Unit

12.4.3 Removal of the F Guide Pole

12.4.4 Removal of the OIS Unit and Shutter Unit

12.4.5 Removal of the Cam Frame Unit

12.4.6 Removal of the Drive Frame Unit

12.4.7 Removal of the 2nd Lens Frame Unit

13 SCHEMATIC DIAGRAMS

13.1 OVER ALL BLOCK DIAGRAM

13.2 WIRING CONNECTION DIAGRAM

13.3 SIDE OPERATION SCHEMATIC DIAGRAM

13.4 SD CARD SCHEMATIC DIAGRAM

13.5 CCD SCHEMATIC DIAGRAM

13.6 TOP OPERATION SCHEMATIC DIAGRAM

13.7 REAR OPERATION SCHEMATIC DIAGRAM

13.8 LENS FLEX SCHEMATIC DIAGRAM

14 CIRCUIT BOARD ASSEMBLIES

14.1 SD CARD C.B.A.

14.2 CCD C.B.A.

14.3 SIDE OPERATION C.B.A.

14.4 LENS FLEX C.B.A.

15 EXPLODED VIEWS

15.1 FRAME & CASING SECTION

15.2 PACKING PARTS & ACCESSORIES SECTION

16 REPLACEMENT PARTS LIST

16.1 MECHANICAL REPLACEMENT PARTS LIST

16.1.1 FRAME & CASING SECTION PARTS LIST

16.1.2 PACKING PARTS & ACCESSORIES SECTION PARTS LIST

16.1.3 SERVICE FIXTURE & TOOLS

16.2 ELECTRICAL REPLACEMENT PARTS LIST